

# 1984 GRUMMAN OLSON KUBVAN

## ILLUSTRATED PARTS MANUAL

Scanned to PDF 2011

Portions of this manual are copyrighted 1983  
Volkswagen of America, Inc.  
Reprinted by permission of VWoA

## SYMBOLS USED

Symbol	Explanation
X	In the quantity column indicates "As required"
( )	The brackets in the key column indicates that the part is not illustrated, but corresponds to the illustration without brackets
MM	Indicates millimeter

## TABLE OF CONTENTS

Page	Subject	Illustration
2	Short engine with crankshaft, pistons, oil pump and oil sump . . . . .	1
4	Cylinder block, oil sump . . . . .	2
6	Cylinder head . . . . .	3
8	Cylinder head cover . . . . .	4
10	Crankshaft . . . . .	5
14	Piston, piston ring . . . . .	6
16	Camshaft, valves . . . . .	7
18	Timing belt cover . . . . .	9
20	Oil pump, oil filter . . . . .	10
22	Water pump . . . . .	11
24	Water cooling . . . . .	14
28	Air duct . . . . .	16
30	Fuel filter . . . . .	19
32	Air cleaner cover, intake manifold . . . . .	23
34	Injection pump, injector, delivery pipes . . . . .	25
38	Clutch . . . . .	32
40	Vacuum pump for brake booster . . . . .	33
42	Engine mount brackets . . . . .	34
44	Engine mounting brackets . . . . .	35
46	Repair kits, engine . . . . .	—
50	Fuel system . . . . .	36
52	Exhaust system . . . . .	43
54	Transmission case for 5 speed manual transmission . . . . .	54
56	Gears and shafts for 5 speed manual transmission . . . . .	56
60	Shift rod, selector shaft, selector forks for 5 speed manual transmission . . . . .	58
62	Transmission case for automatic transmission . . . . .	59
66	Forward, direct and reverse gear clutch torque converter for automatic transmission . . . . .	60
70	Valve body, oil strainer for automatic transmission . . . . .	61
72	Transmission mounting brackets . . . . .	62
74	Wishbone, drive shaft . . . . .	63
78	Differential for manual transmission . . . . .	64
80	Differential for automatic transmission . . . . .	65
82	Axle drive housing for automatic transmission . . . . .	66
87	Repair kit, automatic transmission . . . . .	—
88	Springs, front . . . . .	67
90	Steering gear assy., tie rod . . . . .	68
92	Steering wheel, steering column . . . . .	69
94	Rear axle beam . . . . .	70
96	Back plates and shoes with linings . . . . .	71
98	Parking brake . . . . .	72
100	Wheel discs with caps . . . . .	74
102	Service brake . . . . .	75
104	Brake master cylinder . . . . .	77
106	Brake booster, reservoir for brake master cylinder . . . . .	78
108	Cylinder, wheel brake . . . . .	79
110	Disc brakes (Kelsey-Hayes) . . . . .	83
112	Shift mechanism—manual . . . . .	84
116	Brake and clutch pedal cluster, clutch cable for vehicles with manual transmission . . . . .	88
118	Brake pedal cluster for vehicles with automatic transmission . . . . .	89
120	Accelerator pedal cluster, accelerator cable for vehicles with manual transmission . . . . .	90
122	Accelerator pedal cluster, accelerator cable for vehicles with automatic transmission . . . . .	91
124	Shift mechanism—auto . . . . .	94
127	Repair kits, clutch cable . . . . .	—

## TABLE OF CONTENTS

Page	Subject	Illustration
128	Alternator .....	142
130	Bracket installation for alternator .....	144
132	Belt routing diagrams .....	146
134	Glow plug, current rail .....	148
136	Starting motor .....	152
138	Mounting parts for starting motor .....	153
140	Temperature switch and oil pressure sender .....	155
142	Steering lock, turn signal and wiper/washer switch .....	166
144	Speedometer cable/cold start cable .....	170
146	Electric fan .....	171
148	Battery .....	174
150	Front lights .....	176
152	Rear lights .....	178
154	Instrument panel electric .....	180
156	Dome light/ashtray/cigar lighter .....	182
158	Heater .....	184
160	Windshield wiper .....	186
162	Windshield washer .....	188
164	Misc. electric .....	190
166	Hood assembly .....	192
168	Hood assembly .....	194
170	Roof assembly .....	196
172	Roof assembly .....	198
174	Roof section .....	200
176	Cab assembly .....	202
178	Cab assembly .....	204
180	Firewall assembly .....	206
182	Frame, cab assembly .....	208
184	Dash assembly .....	210
186	Spring support assembly—LH front .....	212
188	Spring support assembly—RH front .....	214
190	Control arm pivot .....	216
192	Track beam assembly .....	218
196	Floor assembly .....	220
198	Floor covering .....	222
200	Side panel assembly .....	224
202	Side door assembly .....	226
204	Spring support assembly—rear .....	228
206	Rear of vehicle .....	230
208	Rear door assembly—2 pc. vertical hinge .....	232
210	Rear door assembly—2 pc. vertical hinge .....	234
212	Rear door latch .....	236
214	Rear door assembly—canopy .....	238
216	Bumpers .....	240
218	Mirrors .....	242
220	Seats/seat belts .....	244
222	Sun visor .....	246
224	Spare tire & jack—standard .....	248
226	Spare tire below floor .....	250
229	Repair kits, misc. ....	—